


W-303B 220...240Vac



See document 9.16.115 for connecting W-303B to a non-Bronkhorst control unit.