

PRESS RELEASE

Compact liquid flow meter without moving parts

Mass Flow ONLINE B.V. presents a new liquid flow meter, available via their internet store. MAG-VIEW™ is a compact, high quality yet economic device for measuring liquid flow rates in applications where flow sensors with moving parts cannot be applied. It's interference free operation, combined with a long-life cycle and independence to the inlet and outlet pipework, makes MAG-VIEW™ the perfect solution even in compact machines and installations. The meter can be used for continuous measurement or for batching and dosing applications.

The MAG-VIEW™ series operates on the magnetic inductive principle and is therefore suitable for electrically conductive liquids with a minimum conductivity of 50 µS/cm. The frequency of the pulse output signal and the optional analog output (4-20 mA) are proportional to the flow. The flow meters feature fast response, low pressure drop and a weatherproof (IP65) enclosure. The instruments can be supplied in three models: for 1...20 l/min, 2...40 l/min and 10...200 l/min.

MAG-VIEW™ can be easily ordered from stock at Mass Flow ONLINE B.V. 24 hours a day, 7 days a week on www.massflow-online.com. From this web shop, we deliver competitively priced, high quality products with excellent delivery time. Your on-line order will be shipped within two working days.

For more information, go to www.massflow-online.com



e-commerce channel of Bronkhorst,
for cost-effective, high quality flow
measurement and control instruments

contact us at: sales@massflow-online.com or
visit our website www.MASSFLOW-ONLINE.com

MAG VIEW



*MAG-VIEW™
flow meter*